

HOLDEN V42.40 Diagnostics List (Note:For reference only)

Diagnostic Menu			Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
(E)2014	Commodore	Engine	3.0L(LFW)		√	√	√	√	
			fuel injector control module		√	√	√		
		Transmission	Transmission Control Module		√	√	√	√	
		Chassis	Electronic Brake Control Module		√	√	√		
		Body	Inflatable Restraint Sensing And Dia		√	√	√	√	
(C)2012	VE&WM Series	Engine	V6		√	√	√	√	
			V6 SIDI		√	√	√	√	
			V8 GENIV		√	√	√		
		Transmission	Automatic Transmisson		√	√	√	√	
		Chassis	Electronic Brake Control Modul		√	√	√	√	
			Fuel Pump Control Module	√	√	√	√	√	
			Esc (Electronic Suspension Con		√	√	√		
		Body	Body Contol Module		√	√	√	√	
			Immobiliser		√	√	√	1. Programming Immobiliser Function 2. Reprogram All Transponder Keys 3. Program Additional Transponder Keys	
			Heating Ventilation and Coolin		√	√	√	√	
			Instrument Panel Cluster		√	√	√	√	1.Program Variant Configuration
			Inflatable Restraint Sensing & Diag. Module		√	√	√		
			Park Assist	√	√	√	√	√	

			RFA(Multipurpose Receiver Modu	√	√	√		1.Erase and Re-Program All Remotes 2.Add Additional Remote 3.TPM Learn Mode 4.Tyre Type/Pressure Selection	
			AHL(Auotmatic Headlamp Lev	√	√	√	√	Basic Position Calibration	
			Memory Seat and Mirrors (M	√	√	√	√		
			Navigation	√	√	√			
			Liftgate Control Module	√	√	√	√		
		Infotainment S	Audio System		√	√	√		
			Rear Seat Entertainment(RS	√	√	√	√		
(B)2011	VE&WM Series	Engine	V6		√	√	√	√	
			V6 SIDI		√	√	√	√	
			V8 GENIV		√	√	√		
		Transmission	Automatic Transmisson		√	√	√	√	
			5 Speed Automatic Transmisson		√	√	√	√	
		Chassis	Electronic Brake Control Module		√	√	√	√	
			Fuel Pump Control Module	√	√	√	√	√	
		Body	Body Contol Module		√	√	√	√	
			Sensing and Diagnostic Module-SRS		√	√	√		
			Instrument Panel Cluster-IPC		√	√	√	√	1.Program Variant Configuration
			Heating Ventilation and Cooling-HVAC		√	√	√	√	

			Multipurpose Receiver Module-RFA	√	√	√		1.Erase and Re-Program All Remotes 2.Add Additional Remote 3.TPM Learn Mode 4.Tyre Type/Pressure Selection	
			Immobiliser		√	√	√	1. Programming Immobiliser Function 2. Reprogram All Transponder Keys 3. Program Additional Transponder Keys	
			Park Assist	√	√	√	√	√	
			Automatic Headlamp Levelling	√	√	√	√	√	Basic Position Calibration
			Memory Seat and Mirrors (MSM)	√	√	√	√	√	
			Navigation	√	√	√			
		Infotainment	Audio		√	√	√		
			Rear Seat Entertainment (RSE)	√	√	√	√	√	
	RA Rodeo	Engine	V6	√	√	√	√		
			4JJ1-TC TRANSTRON		√	√	√		
		Transmission	Automatic Transmisson	√	√	√	√		
			AW30-40LE		√	√	√		
		Chassis	ABS	√	√	√	√		
		Body	Immobilizer	√	√	√	√		
			Immobiliser (Transtron)		√	√	√		
			Airbag		√	√	√		
(A)2010	VE&WM Series	Engine	V6		√	√	√	√	√
			V6 SIDI		√	√	√	√	√
			V8 GENIV		√	√	√	√	√
		Transmission	Automatic Transmisson		√	√	√	√	√
			5 Speed Automatic Transmisson		√	√	√	√	√
		Chassis	Electronic Brake Control Module		√	√	√	√	√

			Fuel Pump Control Module	√	√	√	√	√	√	
		Body	Body Contol Module		√	√	√	√	√	
			Sensing and Diagnostic Module-SRS		√	√	√			
			Instrument Panel Cluster-IPC		√	√	√	√	√	
			Heating Ventilation and Cooling-HVAC		√	√	√			
			Multipurpose Receiver Module-RFA		√	√	√			1.Erase and Re-Program All Remotes 2.Add Additional Remote 3.TPM Learn Mode 4.Tyre Type/Pressure Selection
			Immobiliser		√	√	√			1. Programming Immobiliser Function 2. Reprogram All Transponder Keys 3. Program Additional Transponder Keys
			Park Assist	√	√	√	√	√		
			Automatic Headlamp Levelling	√	√	√	√	√		Basic Position Calibration
			Memory Seat and Mirrors (MSM)	√	√	√	√	√		
			Navigation	√	√	√				
		Infotainment	Audio		√	√	√			
			Rear Seat Entertainment (RSE)	√	√	√	√	√		
	RA Rodeo	Engine	V6	√	√	√	√			
			4JJ1-TC TRANSTRON		√	√	√			
		Transmission	Automatic Transmisson	√	√	√	√			
			AW30-40LE		√	√	√			
		Chassis	ABS	√	√	√	√			
		Body	Immobilizer	√	√	√	√			
			Immobiliser (Transtron)		√	√	√			
			Airbag		√	√	√			

(9)2009	VE&WM Series	Engine	V6		√	√	√	√	√	
			V6 SIDI		√	√	√	√	√	
			V8 GENIV		√	√	√	√	√	
		Transmission	Automatic Transmisson		√	√	√	√	√	
			5 Speed Automatic Transmisson		√	√	√	√	√	
		Chassis	Electronic Brake Control Module		√	√	√	√	√	
			Fuel Pump Control Module	√	√	√	√	√	√	
		Body	Body Contol Module		√	√	√	√	√	
			Sensing and Diagnostic Module-SRS		√	√	√			
			Instrument Panel Cluster-IPC		√	√	√	√	√	
			Heating Ventilation and Cooling- HVAC		√	√	√			
			Multipurpose Receiver Module-RFA		√	√	√			1.Erase and Re-Program All Remotes 2.Add Additional Remote 3.TPM Learn Mode 4.Tyre Type/Pressure Selection
			Immobiliser		√	√	√			1. Programming Immobiliser Function 2. Reprogram All Transponder Keys 3. Program Additional Transponder Keys
			Park Assist	√	√	√	√	√		
			Automatic Headlamp Levelling	√	√	√	√	√		Basic Position Calibration
			Memory Seat and Mirrors (MSM)	√	√	√	√	√		
			Navigation	√	√	√				
		Infotainment	Audio		√	√	√			
			Rear Seat Entertainment (RSE)	√	√	√	√	√		
	RA Rodeo	Engine	V6	√	√	√	√			

			4JJ1-TC TRANSTRON		√	√	√			
		Transmission	Automatic Transmisson	√	√	√	√			
			AW30-40LE		√	√	√			
		Chassis	ABS	√	√	√	√			
		Body	Immobilizer	√	√	√	√			
			Immobiliser (Transtron)		√	√	√			
			Airbag		√	√	√			
(8)2008	VE&WM Series	Engine	V6		√	√	√	√		√
			V6 SIDI		√	√	√	√		√
			V8 GENIV		√	√	√	√		√
		Transmission	Automatic Transmisson		√	√	√	√		√
			5 Speed Automatic Transmisson		√	√	√	√		√
		Chassis	Electronic Brake Control Module		√	√	√	√		√
			Fuel Pump Control Module	√	√	√	√	√		√
		Body	Body Contol Module		√	√	√	√		√
			Sensing and Diagnostic Module-SRS		√	√	√			
			Instrument Panel Cluster-IPC		√	√	√	√		√
			Heating Ventilation and Cooling-HVAC		√	√	√			
			Multipurpose Receiver Module-RFA		√	√	√			1.Erase and Re-Program All Remotes 2.Add Additional Remote 3.TPM Learn Mode 4.Tyre Type/Pressure Selection
			Immobiliser		√	√	√			1. Programming Immobiliser Function 2. Reprogram All Transponder Keys 3. Program Additional Transponder Keys
			Park Assist	√	√	√	√	√		

			Automatic Headlamp Levelling	√	√	√	√	√	Basic Position Calibration
			Memory Seat and Mirrors (MSM)	√	√	√	√	√	
			Navigation	√	√	√			
		Infotainment	Audio		√	√	√		
			Rear Seat Entertainment (RSE)	√	√	√	√	√	
	RA Rodeo	Engine	V6	√	√	√	√		
			4JJ1-TC TRANSTRON		√	√	√		
		Transmission	Automatic Transmisson	√	√	√	√		
			AW30-40LE		√	√	√		
		Chassis	ABS	√	√	√	√		
		Body	Immobilizer	√	√	√	√		
			Immobiliser (Transtron)		√	√	√		
			Airbag		√	√	√		
(7)2007	VE&WM Series	Engine	V6		√	√	√	√	√
			V6 SIDI		√	√	√	√	√
			V8 GENIV		√	√	√	√	√
		Transmission	Automatic Transmisson		√	√	√	√	√
			5 Speed Automatic Transmisson		√	√	√	√	√
		Chassis	Electronic Brake Control Module		√	√	√	√	√
			Fuel Pump Control Module	√	√	√	√	√	√
		Body	Body Contol Module		√	√	√	√	√
			Sensing and Diagnostic Module-SRS		√	√	√		
			Instrument Panel Cluster-IPC		√	√	√	√	√
			Heating Ventilation and Cooling-HVAC		√	√	√		
			Multipurpose Receiver Module-RFA		√	√	√		1.Erase and Re-Program All Remotes 2.Add Additional Remote 3.TPM Learn Mode 4.Tyre Type/Pressure Selection

			Immobiliser		√	√	√		1. Programming Immobiliser Function 2. Reprogram All Transponder Keys 3. Program Additional Transponder Keys
			Park Assist	√	√	√	√	√	
			Automatic Headlamp Levelling	√	√	√	√	√	Basic Position Calibration
			Memory Seat and Mirrors (MSM)	√	√	√	√	√	
			Navigation	√	√	√			
		Infotainment	Audio		√	√	√		
			Rear Seat Entertainment (RSE)	√	√	√	√	√	
	RA Rodeo	Engine	V6	√	√	√	√		
			4JJ1-TC TRANSTRON		√	√	√		
		Transmission	Automatic Transmisson	√	√	√	√		
			AW30-40LE		√	√	√		
		Chassis	ABS	√	√	√	√		
		Body	Immobilizer	√	√	√	√		
			Immobiliser (Transtron)		√	√	√		
			Airbag		√	√	√		
(6)2006	VZ and WL Series	Engine	V6	√	√	√	√	√	√
			V8 GENIV		√	√	√	√	√
		Transmission	Automatic Transmisson	√	√	√	√	√	√
		Chassis	ABS / ESC	√	√	√	√	√	1.Break Bleed(*)
			ABS/TC/ESP 8.0	√	√	√	√		1.Program Configuration 2.Program VIN
		Body	Body Contol Module		√	√	√	√	1.Key Programming(*) 2.User Configure 3.Option
			SRS		√	√	√		
			Instrument		√	√	√	√	1.Instrument Configuration(*)

			Occupant Climate Control		√	√	√	√		
			Audio System		√	√	√	√		
			Powertrain Interface Module	√	√	√	√	√	1.BCM Link to PCM/PIM 2.Program ECU 3.Program Configuration 4.Program VIN	
	RA Rodeo	Engine	V6	√	√	√	√			
			4JJ1-TC TRANSTRON		√	√	√			
		Transmission	Automatic Transmisson	√	√	√	√			
			AW30-40LE		√	√	√			
		Chassis	ABS	√	√	√	√			
		Body	Immobilizer	√	√	√	√			
			Immobiliser (Transtron)		√	√	√			
			Airbag		√	√	√			
(5)2005	VZ and WL Series	Engine	V6		√	√	√	√	√	
			V8 GENIV		√	√	√	√	√	
		Transmission	Automatic Transmisson		√	√	√	√	√	
		Chassis	ABS / ESC		√	√	√	√	1.Break Bleed(*)	
			ABS/TC/ESP 8.0		√	√	√		1.Program Configuration 2.Program VIN	
		Body	Body Contol Module		√	√	√	√	1.Key Programming(*) 2.User Configurte(*) 3.Option(*)	
			SRS		√	√	√			
			Instrument		√	√	√	√	1.Instrument Configuration(*)	
			Occupant Climate Control		√	√	√	√		
			Audio System		√	√	√	√		

									1.BCM Link to PCM/PIM 2.Program ECU 3.Program Configuration 4.Program VIN	
			Powertrain Interface Module	√	√	√	√	√		
(4)2004	VY Series	Engine	V6		√	√	√	√	1.Reset Cell(*)	
		Transmission	Automatic Transmisson		√	√	√	√	1.Reset	
		Chassis	ABS / ESC		√	√	√	√	1.Break Bleed(*)	
		Body	Body Contol Module		√	√	√	√	1.Key Programming(*) 2.User Configurate(*) 3.Option(*)	
			SRS		√	√	√			
			Instrument		√	√	√	√	1.Instrument Configuration(*)	
			Occupant Climate Control		√	√	√	√		
			Audio System		√	√	√	√		
		Vehicle DTC Check								
(3)2003	VY Series	Engine	V6		√	√	√	√	1.Reset Cell(*)	
		Transmission	Automatic Transmisson		√	√	√	√	1.Reset	
		Chassis	ABS / ESC		√	√	√	√	1.Break Bleed(*)	
		Body	Body Contol Module		√	√	√	√	1.Key Programming(*) 2.User Configurate(*) 3.Option(*)	
			SRS		√	√	√			
			Instrument		√	√	√	√	1.Instrument Configuration(*)	
			Occupant Climate Control		√	√	√	√		
			Audio System		√	√	√	√		
		Vehicle DTC Check			√	√	√			
	WH Statesman & Caprice	Engine	V6		√	√	√	√	1.Reset Cell(*)	
			V8 GEN III		√	√	√	√		
		Transmission	Automatic Transmisson		√	√	√	√	1.Reset	

			GEN III Automatic Transmission		√	√	√		
		Chassis	ABS / ESC		√	√	√	√	1.Break Bleed(*)
		Body	Body Contol Module		√	√	√	√	1.Key Programming(*)
			Powertrain Interface Module		√	√	√		
			SRS		√	√	√		
			Instrument		√	√	√	√	1.Instrument Configuration(*)
			Electronic Climate Control		√	√	√	√	
		Vehicle DTC Check			√	√	√		
	Frontera	Powertrain	3.2L V6 6VD1		√	√	√		
		Chassis	ABS		√	√	√		
		Body	Airbag		√	√	√		
			Immobilizer		√	√	√		
	Jackaroo	Powertrain	3.5L V6 6VE1		√	√	√		
(2)2002	VX Commodore	Engine	V6		√	√	√	√	1.Reset Cell(*)
			V8 GEN III		√	√	√	√	
		Transmission	Automatic Transmission		√	√	√		
			GEN III Automatic Transmission		√	√	√		
		Chassis	ABS / ESC		√	√	√		
		Body	Body Contol Module		√	√	√		
			Powertrain Interface Module		√	√	√		
			SRS		√	√	√		
			Instrument		√	√	√		
			Electronic Climate Control		√	√	√		
		Vehicle DTC Check							
	WH Statesman & Caprice	Engine	V6		√	√	√	√	1.Reset Cell(*)
			V8 GEN III		√	√	√	√	
		Transmission	Automatic Transmisson		√	√	√		
			GEN III Automatic Transmission		√	√	√		
		Chassis	ABS / ESC		√	√	√	√	1.Break Bleed(*)
		Body	Body Contol Module		√	√	√	√	1.Key Programming(*)
			Powertrain Interface Module		√	√	√		
			SRS		√	√	√		

			Instrument	√	√	√	√	1.Instrument Configuration(*)
			Electronic Climate Control	√	√	√	√	
		Vehicle DTC Check						
	VU Utility	Engine	V6	√	√	√	√	1.Reset Cell(*)
			V8 GEN III	√	√	√	√	
		Transmission	Automatic Transmisson	√	√	√		
			GEN III Automatic Transmission	√	√	√		
		Chassis	ABS / ESC	√	√	√	√	1.Break Bleed(*)
		Body	Body Contol Module	√	√	√	√	1.Key Programming(*)
			Powertrain Interface Module	√	√	√		
			SRS	√	√	√		
			Instrument	√	√	√	√	1.Instrument Configuration(*)
			Electronic Climate Control	√	√	√	√	
		Vehicle DTC Check						
	Rodeo	Powertrain	3.2L V6 6VD1 Hitachi	√	√	√		
			2.2L L4 SOHC	√	√	√		
	Frontera		4JH1-TC BOSCH	√	√	√		
		Body	Immobilizer	√	√	√		
		Powertrain	3.2L V6 6VD1	√	√	√		
		Chassis	ABS	√	√	√		
	Jackaroo	Body	Airbag	√	√	√		
			Immobilizer	√	√	√		
		Powertrain	3.5L V6 6VE1	√	√	√		
(1)2001	VX Commodore	Engine	V6	√	√	√	√	1.Reset Cell(*)
			V8 GEN III	√	√	√	√	
		Transmission	Automatic Transmission	√	√	√		
			GEN III Automatic Transmission	√	√	√		
		Chassis	ABS / ESC	√	√	√	√	1.Break Bleed(*)
		Body	Body Contol Module	√	√	√	√	1.Key Programming(*)
			Powertrain Interface Module	√	√	√		
			SRS	√	√	√		

			Instrument	√	√	√	√	1.Instrument Configuration(*)
			Electronic Climate Control	√	√	√	√	
		Vehicle DTC Check						
	WH Statesman & Caprice	Engine	V6	√	√	√	√	1.Reset Cell(*)
			V8 GEN III	√	√	√	√	
		Transmission	Automatic Transmisson	√	√	√		
			GEN III Automatic Transmission	√	√	√		
		Chassis	ABS / ESC	√	√	√	√	1.Break Bleed(*)
		Body	Body Contol Module	√	√	√	√	1.Key Programming(*)
			Powertrain Interface Module	√	√	√		
			SRS	√	√	√		
			Instrument	√	√	√	√	1.Instrument Configuration(*)
			Electronic Climate Control	√	√	√	√	
		Vehicle DTC Check						
	VU Utility	Engine	V6	√	√	√	√	1.Reset Cell(*)
			V8 GEN III	√	√	√	√	
		Transmission	Automatic Transmisson	√	√	√		
			GEN III Automatic Transmission	√	√	√		
		Chassis	ABS / ESC	√	√	√	√	1.Break Bleed(*)
		Body	Body Contol Module	√	√	√	√	1.Key Programming(*)
			Powertrain Interface Module	√	√	√		
			SRS	√	√	√		
			Instrument	√	√	√	√	1.Instrument Configuration(*)
			Electronic Climate Control	√	√	√	√	
		Vehicle DTC Check						
	Rodeo	Powertrain	3.2L V6 6VD1 Hitachi	√	√	√		
			2.2L L4 SOHC	√	√	√		
			4JH1-TC BOSCH	√	√	√		
		Body	Immobilizer	√	√	√		
	Frontera	Powertrain	3.2L V6 6VD1	√	√	√		
		Chassis	ABS	√	√	√		

		Body	Airbag		√	√	√		
			Immobilizer		√	√	√		
	Jackaroo	Powertrain	3.5L V6 6VE1		√	√	√		
(Y)2000	VT Commodore	Engine	V6		√	√	√	√	1.Reset Cell(*)
			V6 Supercharged		√	√	√	√	1.Reset Cell(*)
			V8		√	√	√	√	1.Reset Cell(*)
			V8 GEN III		√	√	√	√	
			V6 LPG		√	√	√	√	1.Reset Cell(*)
		Transmission	Automatic Transmisson		√	√	√		
			GEN III Automatic Transmission		√	√	√	√	
		Chassis	ABS / EST		√	√	√	√	1.Break Bleed(*)
		Body	Body Contol Module		√	√	√	√	1.Key Programming(*)
			Powertrain Interface Module		√	√	√		
			SRS		√	√	√		
			Instrument		√	√	√	√	1.Instrument Configuration(*)
			Electronic Climate Control		√	√	√	√	
		Vehicle DTC Check							
	WH Statesman & Caprice	Engine	V6		√	√	√	√	1.Reset Cell(*)
			V6 Supercharged		√	√	√	√	1.Reset Cell(*)
			V8		√	√	√	√	1.Reset Cell(*)
			V8 GEN III		√	√	√	√	
			V6 LPG		√	√	√	√	1.Reset Cell(*)
		Transmission	Automatic Transmisson		√	√	√		
			GEN III Automatic Transmission		√	√	√	√	
		Chassis	ABS / EST		√	√	√	√	1.Break Bleed(*)
		Body	Body Contol Module		√	√	√	√	1.Key Programming(*)
			Powertrain Interface Module		√	√	√		
			SRS		√	√	√		
			Instrument		√	√	√	√	1.Instrument Configuration(*)
			Electronic Climate Control		√	√	√	√	
		Vehicle DTC Check							

	Rodeo	Powertrain	3.2L V6 6VD1 Hitachi		√	√	√		
			2.2L L4 SOHC		√	√	√		
	Frontera	Powertrain	3.2L V6 6VD1		√	√	√		
	Jackaroo	Powertrain	3.5L V6 6VE1		√	√	√		
(X)1999	VT Commodore	Engine	V6		√	√	√	√	1.Reset Cell(*)
			V6 Supercharged		√	√	√	√	1.Reset Cell(*)
			V8		√	√	√	√	1.Reset Cell(*)
			V8 GEN III		√	√	√	√	
			V6 LPG		√	√	√	√	1.Reset Cell(*)
		Transmission	Automatic Transmisson		√	√	√		
			GEN III Automatic Transmission		√	√	√	√	
		Chassis	ABS / EST		√	√	√	√	1.Break Bleed(*)
		Body	Body Contol Module		√	√	√	√	1.Key Programming(*)
			Powertrain Interface Module		√	√	√		
			SRS		√	√	√		
			Instrument		√	√	√	√	1.Instrument Configuration(*)
			Electronic Climate Control		√	√	√	√	
		Vehicle DTC Check							
	VS Commodore	Engine	V8		√	√	√		
		Transmission	Automatic Transmission		√	√	√		
	WH Statesman & Caprice	Engine	V6		√	√	√	√	1.Reset Cell(*)
			V6 Supercharged		√	√	√	√	1.Reset Cell(*)
			V8		√	√	√	√	1.Reset Cell(*)
			V8 GEN III		√	√	√	√	
			V6 LPG		√	√	√	√	1.Reset Cell(*)
		Transmission	Automatic Transmisson		√	√	√		
			GEN III Automatic Transmission		√	√	√	√	
		Chassis	ABS / EST		√	√	√	√	1.Break Bleed(*)
		Body	Body Contol Module		√	√	√	√	1.Key Programming(*)
			Powertrain Interface Module		√	√	√		
			SRS		√	√	√		

			Instrument	√	√	√	√	1.Instrument Configuration(*)
			Electronic Climate Control	√	√	√	√	
		Vehicle DTC Check						
	Rodeo	Powertrain	3.2L V6 6VD1 Hitachi	√	√	√		
			2.2L L4 SOHC	√	√	√		
			4L30E	√	√	√	√	
	Frontera	Powertrain	3.2L V6 6VD1	√	√	√		
	Jackaroo	Powertrain	3.5L V6 6VE1	√	√	√		
(W)1998	VT Commodore	Engine	V6	√	√	√	√	1.Reset Cell(*)
			V6 Supercharged	√	√	√	√	1.Reset Cell(*)
			V8	√	√	√	√	1.Reset Cell(*)
			V6 LPG	√	√	√	√	1.Reset Cell(*)
		Transmission	Automatic Transmisson	√	√	√		
		Chassis	ABS / EST	√	√	√	√	1.Break Bleed(*)
		Body	Body Contol Module	√	√	√	√	1.Key Programming(*)
			SRS	√	√	√		
			Instrument	√	√	√	√	1.Key Programming(*)
			Electronic Climate Control	√	√	√	√	
		Vehicle DTC Check						
	VS Commodore	Engine	V8	√	√	√	√	
		Transmission	Automatic Transmission	√	√	√		
	Rodeo	Powertrain	3.2L V6 6VD1 Hitachi	√	√	√		
			2.2L L4 SOHC	√	√	√		
			4L30E	√	√	√	√	
	Jackaroo	Powertrain	3.5L V6 6VE1	√	√	√		
(V)1997	VT Commodore	Engine	V6	√	√	√	√	1.Reset Cell(*)
			V6 Supercharged	√	√	√	√	1.Reset Cell(*)
			V8	√	√	√	√	1.Reset Cell(*)
			V6 LPG	√	√	√	√	1.Reset Cell(*)

		Transmission	Automatic Transmisson		√	√	√		
		Chassis	ABS / EST		√	√	√	√	1.Break Bleed(*)
		Body	Body Contol Module		√	√	√	√	1.Key Programming(*)
			SRS		√	√	√		
			Instrument		√	√	√	√	1.Key Programming(*)
			Electronic Climate Control		√	√	√	√	
		Vehicle DTC Check							
(-U)- 1996	VS Commodore	Engine	V6		√	√	√	√	
			V8		√	√	√	√	
		Transmission	V6		√	√	√		
			V8		√	√	√		
		Chassis	ABS / ESC		√	√	√		
		Body	Body Contol Module		√	√	√	√	1.Key Programming(*)
			SRS		√	√	√		
	VR Commodore	Engine	V6		√	√	√	√	
			V8		√	√	√	√	
		Transmission	Automatic Transmission		√	√	√		
		Chassis	ABS / ESC		√	√	√		
		Body	Body Contol Module		√	√	√	√	
			Theft Deterrent Module		√	√			1.Key Programming
	VN Commodore	Engine	3.8L		√	√			
			5.0L		√	√			
	VP Commodore	Engine	3.8L		√	√			
			5.0L		√	√			
	VL Commodore	Engine	3.8L		√	√			
			5.0L		√	√			
(*) :Tested;									